

EXPLORER™ 500

QUICK GUIDE

Start up

1. Connect the cable(s).
2. Press and hold the power button next to the display until the green power indicator lights up.
3. Enter the PIN if required.
4. Adjust the antenna position to obtain the maximum signal strength, and accept.

NOTE: If you need to reposition the antenna later, enter the display menu system and select **SETTINGS > POINT NOW**.

When the display shows **READY** you can make a call or a data session.

Voice call

To make a call from the EXPLORER™ 500, dial: **00 <country code> <phone number>** followed by **#** or off-hook key.

Example: Thrane & Thrane A/S in Denmark:
00 45 39558800 #

To make a call to a phone connected to the EXPLORER™ 500, dial:
+870 <mobile number>


Fax call

Dial:

00 <country code> <phone number> #

Example: Thrane & Thrane A/S in Denmark:
00 45 39558888 #

NOTE: If 3.1kHz Audio is not selected as default, dial **2 *** before the number.



Local call

To make a local call from a Bluetooth phone to a standard phone, dial:
301 followed by off-hook key.

To make a local call from a standard phone to a Bluetooth phone, dial the number of the Bluetooth phone followed by **#**.

Connecting LAN

1. Connect the LAN cable between the data equipment and the EXPLORER™ 500 and turn on both units.
2. Go through the start up procedure for the EXPLORER™ 500. When the EXPLORER™ 500 is ready, the data connection is established automatically.
3. Use your Internet browser or e-mail program.

Thrane & Thrane

Connecting USB

1. Connect the USB cable between the data equipment and the EXPLORER™ 500 and turn on both units.
2. Go through the start up procedure for the EXPLORER™ 500.
3. Open the dial-up connection you are using for your USB connection.
4. Use your Internet browser or e-mail program.

Connecting Bluetooth

1. Place the Bluetooth device close to the EXPLORER™ 500.
2. Turn on Bluetooth on your device.
3. Select the EXPLORER™ 500 from your device.
4. Use your Internet browser or e-mail program.

NOTE: If the two devices have not been connected before, you have to pair them using a passkey. See the user manual for EXPLORER™ 500 for further information.

Launching the web interface

1. Connect a PC to the EXPLORER™ 500.
2. Start your Internet browser.
3. Enter the IP address of the web interface. The IP address is found in the menu system, by selecting **PROPERTIES-TERMINAL>IP ADDRESS**.

Send SMS

1. In the Web Server, select **Messages > Write Message**
2. Type the message.
3. Select the phone number from the phone book or type it in as follows:
00 <country code> <phone number>.
4. Select Delivery Notification **on** or **off**.
5. Click **Send**.

Shortcuts in the menu system

To turn pointing sound on/off press ▲ or ▼.
To activate stealth mode, press **C + OK**.
To exit the menu system, press and hold **C** for one second.

DISPLAY MENUS

